




Compatible Devices for iBox BT

Android™	Apple®	BlackBerry®										
<p>Requirements:</p> <ul style="list-style-type: none"> phones or tablets with OS 2.1 or newer a cellular data plan a current eKEY application downloaded on the device from the Google Play™ Store app 	<p>Requirements:</p> <ul style="list-style-type: none"> phones or tablets with iOS 4.3 or newer a cellular data plan a current eKEY application downloaded on the device from App Store™ 	<p>Requirements:</p> <ul style="list-style-type: none"> phones or tablets with OS 5 or newer, except the BlackBerry 10 a cellular data plan a current eKEY application downloaded on the device from BlackBerry App World™ 										
<p>A Supra® eKEY Fob is not required to open the iBox BT device.</p> <div data-bbox="107 688 558 848" style="border: 1px solid black; padding: 5px; text-align: center;">  <p>Supra eKEY Fob</p> </div> <p>Some Example Devices:</p> <p>Droid 2 Droid X EVO™ Galaxy™S5, S4, S3, S2, & S Galaxy Note™ 4, 3, & 2 Hero™ Incredible Nexus One™ Nexus™ 4</p>	<p>To access the iBox BT for all models, a Supra® Fob or Adapter is required. For more adapter information, click here.</p> <p>To access the iBox BT using the Supra eKEY Adapter, Apple models with the Lightning™ 8-pin connector port (i.e. iPhone 5 and newer, iPad 4 and newer, and iPad Mini), require an additional Apple Lightning™ Adapter.</p> <div data-bbox="586 974 1037 1178" style="border: 1px solid black; padding: 5px; text-align: center;">  <p>Supra eKEY Fob Supra eKEY Adapter Lightning Adapter</p> </div> <p>Some Example Devices:</p> <table border="0"> <tr> <td>iPhone®</td> <td>iPad®</td> </tr> <tr> <td>iPhone 6 & 6 Plus</td> <td>iPad Mini</td> </tr> <tr> <td>iPhone 5s, 5c, & 5</td> <td>iPad 4G</td> </tr> <tr> <td>iPhone 4s & 4</td> <td>iPad 3G (Retina display)</td> </tr> <tr> <td>iPhone 3GS</td> <td>iPad 2G</td> </tr> </table>	iPhone®	iPad®	iPhone 6 & 6 Plus	iPad Mini	iPhone 5s, 5c, & 5	iPad 4G	iPhone 4s & 4	iPad 3G (Retina display)	iPhone 3GS	iPad 2G	<p>A Supra® eKEY Fob is not required to open the iBox BT device.</p> <div data-bbox="1062 688 1513 848" style="border: 1px solid black; padding: 5px; text-align: center;">  <p>Supra eKEY Fob</p> </div> <p>Some Example Devices:</p> <p>8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™</p> <p>NOTE: The BlackBerry 10 is not supported at this time.</p>
iPhone®	iPad®											
iPhone 6 & 6 Plus	iPad Mini											
iPhone 5s, 5c, & 5	iPad 4G											
iPhone 4s & 4	iPad 3G (Retina display)											
iPhone 3GS	iPad 2G											

Please contact Support at 1-877-699-6787 if you have a question about a specific device.

<p>Compatible eKEY Devices List Click Here</p>	<p>New Zealand eKEY Customers Click Here</p>	<p>Supra eKEY Adapter for Apple Products, Click Here</p>
---	---	---

www.supraekey.com

